



DigiBoard - Trim and Tape Range

This range of products are ideally suited to quantities from 25 to 250 sheets, therefore all products require trimming with a guillotine and some require fixing using double sided tape.



DigiBoard - Perf and Tab Range


This range of products is designed to simply tear out of the printed sheet and tab together. Ideally suited to one off applications such as the Xerox Kiosk.



¹This product cannot be printed on. The printable Wine Sleeve wraps around this box to give the look of a printed carton.
²This product cannot be printed on. The printable Gift Box Lid fits on top of this box base.


DigiBoard - How it Works

Step 1...




Take a pre-creased DigiBoard sheet.

Step 2...



Print with a Xerox digital press.

Step 3...



Trim with a guillotine or simply tear off excess board.

Step 4.



Fold and make up.